

Turbine STEP Float Trees

A Convenient Assembly For Organizing Float Switches Inside A Turbine Step Vault



Floats not included.

Features


- Various float tree lengths to match STEP vault heights
- Two to five hanger float trees are available
- Easy to install and remove for maintenance
- Designed for use in turbine STEP system applications
- Twist-and-grip technology to secure and tether the float cord



Trusted. Tested. Tough.®

zoellerpumps.com 800-928-7867
3649 Cane Run Road, Louisville, KY 40211 USA

CL0023
0121
Supersedes
0219



Floats not included.



Zoeller Pump Company Float Trees feature snap-on and twist-and-grip holder technologies.

Turbine STEP Float Trees	
Part Number	Description
10-1672	2-Hanger Float tree, 60"
10-1673	3-Hanger Float tree, 60"
10-1674	4-Hanger Float tree, 60"
10-1726	5-Hanger Float tree, 60"
10-1741	3-Hanger Float tree, 84"
10-1746	3-Hanger Float tree, 96"
10-1792	3-Hanger Float tree, 51"
10-1793	4-Hanger Float tree, 96"
10-1932	2-Hanger Float tree, 72"
10-1933	2-Hanger Float tree, 96"
10-2136	2-Hanger Float tree, 51"
10-2152	4-Hanger Float tree, 120"
10-2180	4-Hanger Float tree, 90"
10-2196	4-Hanger Float tree, 72"
10-2209	4-Hanger Float tree, 84"
10-2260	4-Hanger Float tree, 51"